


BOLD

3


Mantenimiento del carrete.

Maintenance of reel
/ Entretien du moulinet



Engrase de la zona del planetario.


Lubricate gear area
/ Graisser la zone de l'engrenage épicycloïdal




Engrase de la zona posterior.

Lubricate back area
/ Graissage de la zone arrière


a Remove back cover / Enlever le couvercle arrière



- b Engrasar zona piñón
/ Lubricate pinion
/ Graisser le pignon



- c Engrasar zona palanca
/ Lubricate lever / Graisser la
zone de la manivelle



- d Poner tapa / Replace cover
/ Remettre le couvercle